

IMPORTANT INSTALLATION NOTICE FOR DM1 (MULTIZONE DIY MINI SPLITS)

Quick Connect Fitting Adapter Replacement

Locating the Adapters: Please check your packaging carefully. The required quick connect fitting adapters are safely secured **inside the blue protective foam** within the main box.

Installation Instructions

1. **Remove Existing Fittings:** Using a set of wrenches (always use a backup wrench on the valve body to prevent twisting), loosen and completely remove the factory-installed quick connect fittings and flare nuts from the outdoor unit's ports.
2. **Verify Exposed Threads:** Removing the original fittings will expose the standard threaded fittings underneath.
3. **Install New Adapters:** Thread the new, included quick connect fitting adapters directly onto the newly exposed standard fittings, then firmly tighten them down using your wrenches.

Critical Note Regarding Refrigerant

You will **not** experience any refrigerant loss during this fitting swap. The key to preventing loss is ensuring that **all service valves remain completely closed** throughout the entire process. Do not open any valves until your lineset is fully connected and secured.