


Pipe Joint Subassembly Spec and Notices for Installation

1. Notices for Installation:

During the installation of the unit, the installation space of the pipe joint assembly should be taken into account. See the figure below for its installation dimension. (mm)



2. Pipe Joint Subassembly Spec:

Serial No.	Pipe Joint Subassembly Spec (①→②)	SizeL1 (mm)	SizeL2 (mm)	Quantity
1	6.35→9.52	72	91	2
2	12.7→9.52	100	118	2
3	12.7→15.9	99	141	2
4	9.52→6.35	100	137	1
5	15.9→9.52	144	226	1
6	9.52→12.7	99	119	1
7	15.9→12.7	144	176	1

