




REPAIR PARTS

GMES 96% High Efficient Furnace

GMES960403ANAA
GMES960603BNAA
GMES960803BNAA
GMES960804CNAA
GMES960805CNAA
GMES961005CNAA
GMES961205DNAA



This manual is to be used by qualified technicians only.

© 2019 Goodman Manufacturing Company, L.P. ♦ 5151 San Felipe St, Suite 500 ♦ Houston, TX 77056

Important Information

Index

Functional Parts List	3
Illustration and Parts	4 - 11

Views shown are for parts illustrations only, not servicing procedures

Text Codes:

AR - As Required

NA - Not Available

NS - Not Shown

00000000 - See Note

QTY - Quantity Example (QTY 3) (If Quantity not shown, Quantity = 1)

M - Model Example (M1) (If M Code not shown, then part is used on all Models)

Expanded Model Nomenclature:

Example M1 - Model#1 M2 - Model#2 M3 - Model#3

Goodman Manufacturing Company, L.P. is not responsible for personal injury or property damage resulting from improper service. Review all service information before beginning repairs.

Warranty service must be performed by an authorized technician, using authorized factory parts. If service is required after the warranty expires, Goodman Manufacturing Company, L.P. also recommends contacting an authorized technician and using authorized factory parts.

Goodman Manufacturing Company, L.P. reserves the right to discontinue, or change at any time, specifications or designs without notice or without incurring obligations.

For assistance within the U.S.A. contact:

Homeowner Support

Goodman Manufacturing Company, L.P.

19001 Kermier Road

Waller, Texas 77484

877-254-4729-Telephone

713-863-2382-Facsimile

For assistance outside the U.S.A. contact:

International Division

Goodman Manufacturing Company, L.P.

19001 Kermier Road

Waller, Texas 77484

713-861-2500-Telephone

713-863-2382-Facsimile

Functional Parts

Part

No: **Description:**

20162904	*PRIMARY LIMIT-TEMPERATURE CONTROL (M3, M6, M7) *Refer to service bulletin SF-054
0257F00446	ASSY, HEAT EXCHANGER (M1)
0163F00017	BECKETT BURNER (QTY 2)
0271F00159	BLOWER SHELL & WHEEL ASSY (M2, M3)
0271F00161	BLOWER SHELL & WHEEL ASSY (M4, M5, M6)
0271F00163	BLOWER SHELL & WHEEL ASSY (M7)
0271F00322	BLOWER SHELL & WHEEL ASSY (M1)
PCBBF145	CIRCUIT BOARD
0130F00010	FLAME SENSOR
0151M00037	GAS VALVE
0257F00240	HEAT EXCHANGER ASSY (M4, M5)
0257F00257	HEAT EXCHANGER ASSY (M7)
0257F00280	HEAT EXCHANGER ASSY (M6)
0257F00374	HEAT EXCHANGER ASSY (M2)
0257F00379	HEAT EXCHANGER ASSY (M3)
0130F00008	IGNITOR-SINI 17 SEC
0130M00243	INTERLOCK SWITCH
10123538	MANUAL RESET LIMIT - ROS (M3, M6)
10123539	MANUAL RESET LIMIT - ROS (M2, M4)
10123528	MANUAL RESET LIMIT - ROS (M7)
0130F00123	MANUAL RESET LIMIT - ROS (M5)
10123533	MANUAL RESET LIMIT - ROS (M1)
0131F00112	MOTOR X-13, BLOWER 1/2 H.P. (M1, M2, M3)
0131F00114	MOTOR X-13, BLOWER 1H.P. (M5, M6, M7)
0131F00113	MOTOR X-13, BLOWER 3/4 H.P. (M4)
0131F00143	MOTOR, PROGRAM-X13 (M1)
0131F00148	MOTOR, PROGRAM-X13 (M6)
0131F00147	MOTOR, PROGRAM-X13 (M5)
0131F00146	MOTOR, PROGRAM-X13 (M4)
0131F00145	MOTOR, PROGRAM-X13 (M3)
0131F00144	MOTOR, PROGRAM-X13 (M2)
0131F00149	MOTOR, PROGRAM-X13 (M7)
0130F00642	PRESSURE SWITCH (M1)
20162903	PRIMARY LIMIT - BLUE (M1, M2, M4, M5)
0130F00038	PRIMARY LIMIT - LT BLUE 120° (AUX) (QTY 2)
0130F00438	SWITCH, PRESSURE (M7)
0130F00439	SWITCH, PRESSURE (M3, M4, M5, M6)
0130F00440	SWITCH, PRESSURE (M2)



SPECIAL PARTS

0161F00086 NAMEPLATE, GOODMAN

Expanded Model Nomenclature

M1 - GMES960403ANAA
M2 - GMES960603BNAA
M3 - GMES960803BNAA
M4 - GMES960804CNAA
M5 - GMES960805CNAA
M6 - GMES961005CNAA
M7 - GMES961205DNAA

Cabinet Assembly



DRAIN TRAP ASSEMBLY

Cabinet Assembly

Ref. Part No: No:	Description:	Ref. Part No: No:	Description:
Image 1:			
111	0154F00024		GASKET (QTY 2)
121	0154F00025		GASKET (QTY 2)
141	0161F00046		DRAIN TRAP
191	0121F00291DG		DOOR, ACCESS 17.5 PNT (M2, M3)
191	0121F00292DG		DOOR, ACCESS 21 PNT (M4, M5, M6)
191	0121F00293DG		DOOR, ACCESS 24.5 PNT (M7)
191	0121F00674DG		PNT, DOOR, ACCESS 14" (M1)
201	0121F00288DG		DOOR, BLOWER 17.5 PNT (M2, M3)
201	0121F00289DG		DOOR, BLOWER 21 PNT (M4, M5, M6)
201	0121F00290DG		DOOR, BLOWER 24.5 PNT (M7)
201	0121F00672DG		PNT, DOOR, BLOWER 14" (M1)
281	B1392139		VIEW PORT BUSHING-BLOWER DOOR (QTY 2)
311	0154F00020		GASKET, DECK (M2, M3)
311	0154F00021		GASKET, DECK (M4, M5, M6)
311	0154F00022		GASKET, DECK (M7)
311	0154F00063		GASKET, DECK (M1)
341	0164F00017		HOSE-ELBOW/TRAP
351	0164F00020		DRAIN HOSE (M1)
351	0164F00006		HOSE, COVER/TRAP (M2, M3, M4, M5, M6, M7)
381	0161F00047		COUPLING, HOSE BARBED
451	M0501301		PIPE GROMMET
491	M0570808		BUTTON PLUG (QTY 3)
501	M0570806		BUTTON PLUG
511	M0570807		BUTTON PLUG
521	0161M00027		PLUG, HOLE (M1, M2, M3, M6)
601	B1392021		PLASTIC PLUG, 1" (2713-BLK) (QTY 4)
741	B1392104		UNIVERSAL BUSHING UB 875
NS	M0310345		BUTTON PLUG (QTY 2)
NS	0270F04115		DRAIN KIT ASSY UF
NS	0163M00319		HEX NUT-INSERT (QTY 3)
NS	0161F00086		NAMEPLATE, GOODMAN
NS	M0273904		RETAINER-SCREW (QTY 3)
NS	M0209730		SCREW-DECORATIVE (QTY 3)

Expanded Model Nomenclature

M1 - GMES960403ANAA M2 - GMES960603BNAA M3 - GMES960803BNAA M4 - GMES960804CNAA M5 - GMES960805CNAA M6 - GMES961005CNAA M7 - GMES961205DNAA

Blower Assembly


BLOWER ASSEMBLY

*If end bells are needed please order the following:

0131M00182 - ½ HP

0131M00183 - ¾ HP

0131M00184 - 1 HP



BLOWER ASSEMBLY MAY DIFFER FROM WHAT IS SHOWN


Blower Assembly

Ref. Part No: No:	Description:	Ref. Part No: No:	Description:
Image 1:			
31	0271F00159		BLOWER SHELL & WHEEL ASSY (M2, M3)
31	0271F00161		BLOWER SHELL & WHEEL ASSY (M4, M5, M6)
31	0271F00163		BLOWER SHELL & WHEEL ASSY (M7)
31	0271F00322		BLOWER SHELL & WHEEL ASSY (M1)
141	0121M00039		MOUNT BAND, MOTOR (HEAVY DUTY)
151	B1376863		MOUNT ARM, MOTOR (HEAVY DUTY) (QTY 3)
181	0131F00112		MOTOR X-13, BLOWER 1/2 H.P. (M1, M2, M3)
181	0131F00114		MOTOR X-13, BLOWER 1H.P. (M5, M6, M7)
181	0131F00113		MOTOR X-13, BLOWER 3/4 H.P. (M4)
231	M0250565		SCREW-TC 1.25" (QTY 3)
251	0163M00320		HEX HEAD ALL THREAD TAP BOLT
261	B1392918		WASHER, FLAT 1/4 ID X 1 OD (QTY 3)
281	B1393800		LOCKNUT, NYLON, INSERT 1/4,20
381	0130M00140		TRANSFORMER 120V TO 24V, 40VA
401	PCBBF145		CIRCUIT BOARD
461	0121F00464		MOUNTING PLATE-CONTROLS
521	0130F00038		PRIMARY LIMIT - LT BLUE 120° (AUX) (QTY 2)
NS	0131F00143		MOTOR, PROGRAM-X13 (M1)
NS	0131F00144		MOTOR, PROGRAM-X13 (M2)
NS	0131F00145		MOTOR, PROGRAM-X13 (M3)
NS	0131F00146		MOTOR, PROGRAM-X13 (M4)
NS	0131F00147		MOTOR, PROGRAM-X13 (M5)
NS	0131F00148		MOTOR, PROGRAM-X13 (M6)
NS	0131F00149		MOTOR, PROGRAM-X13 (M7)
NS	B1392021		PLASTIC PLUG, 1" (2713-BLK) (QTY 4)
NS	0259F00024		WIRE HARNESS-BLOWER

Expanded Model Nomenclature

M1 - GMES960403ANAA
M2 - GMES960603BNAA
M3 - GMES960803BNAA
M4 - GMES960804CNAA
M5 - GMES960805CNAA
M6 - GMES961005CNAA
M7 - GMES961205DNAA

Chassis Assembly



Chassis Assembly

Ref. Part

No: No:

Description:

Ref. Part

No: No:

Description:


Image 1:

11	0121F00530DG	BASEPAN, 17.5 (M2, M3)
11	0121F00531DG	BASEPAN, 21 PNT (M4, M5, M6)
11	0121F00532DG	BASEPAN, 24.5 PNT (M7)
11	0121F00664DG	BASEPAN, 14 PNT (M1)
31	0121F00663	DECK, BLOWER 14" (M1)
31	0121F00533	DECK-BLOWER 17.5" (M2, M3)
31	0121F00534	DECK-BLOWER 21" (M4, M5, M6)
31	0121F00535	DECK-BLOWER 24.5" (M7)
91	0160F00025	INSULATION, HT EXCHANGER (M1)
91	0160F00025	INSULATION, HT EXCHANGER (M1)
91	0160F00025	INSULATION, HT EXCHANGER (M1)
91	0160F00025	INSULATION, HT EXCHANGER (M1)
101	0121F00314	ANGLE, DECK (M2, M3)
101	0121F00315	ANGLE, DECK (M4, M5, M6)
101	0121F00316	ANGLE, DECK (M7)
101	0121F00661	ANGLE, DECK (M1)
111	0121F00279DG	PAINTED TOP, FURNACE 17.5 (M2, M3)
111	0121F00280DG	PAINTED TOP, FURNACE 21 (M4, M5, M6)
111	0121F00281DG	PAINTED TOP, FURNACE 24.5 (M7)
111	0121F00662DG	PNT, FURNACE TOP 14" (M1)
121	0121F00313	ANGLE, SIDE (QTY 2)
191	0164M00015	PRESSURE SWITCH HOSE
201	0164M00008	HOSE-PRESSURE SW (M1, M2, M4, M5, M6, M7)
201	0164M00009	HOSE-PRESSURE SW (M3)
221	0130M00243	INTERLOCK SWITCH
231	0164F00002	FLUE PIPE W/BEND
241	0164F00001	ELBOW-FLUE, UPFLOW
251	0154F00041	FRESH AIR GASKET
271	0171M00008	MOTOR, ID BLOWER (M1)
271	0171M00001	MOTOR-ID, BLOWER (M2, M3, M4, M5, M6, M7)
281	0161F00037	COUPLING
291	0130F00642	PRESSURE SWITCH (M1)
291	0130F00438	SWITCH, PRESSURE (M7)
291	0130F00439	SWITCH, PRESSURE (M3, M4, M5, M6)
291	0130F00440	SWITCH, PRESSURE (M2)
311	0161F00042	JUNCTION BOX PLA
331	0161F00043	JUNCTION BOX LID
611	0163M00460	CLAMP-HOSE (QTY 2)
791	0154F00015	GASKET (QTY 2)
811	0154F00064	GASKET (M1)
811	20179307	GASKET (M7)
811	20179309	GASKET (M2, M3)
811	20179310	GASKET (M4, M5, M6)
991	0121F00389	BRACKET, DOOR SWITCH
NS	0159F00067	HARNESS, WIRING (M4, M5, M6, M7)
NS	0159F00098	HARNESS, WIRING (M1, M2, M3)
NS	M0326804	PLUG-TUBE
NS	0159F00076	WIRING HARNESS

Expanded Model Nomenclature

M1 - GMES960403ANAA
M2 - GMES960603BNAA
M3 - GMES960803BNAA
M4 - GMES960804CNAA
M5 - GMES960805CNAA
M6 - GMES961005CNAA
M7 - GMES961205DNAA

Heat Exchange Assembly



Heat Exchange Assembly

Ref. Part No: No:	Description:	Ref. Part No: No:	Description:	
Image 1:		Image 1:		
11	0130F00008	IGNITOR-SINI 17 SEC	271 0154F00058	GASKET REAR CVR (M1)
21	0151M00037	GAS VALVE	271 0154F00037	GASKET, REAR CVR (M2, M3)
31	10716005	ORIFICE (QTY 2)	271 0154F00038	GASKET, REAR CVR (M4, M5, M6)
41	0130F00010	FLAME SENSOR	271 0154F00039	GASKET, REAR CVR (M7)
51	0130F00123	MANUAL RESET LIMIT - ROS (M5)	371 20162904	*PRIMARY LIMIT-TEMPERATURE CONTROL (M3, M6, M7)
51	10123528	MANUAL RESET LIMIT - ROS (M7)		*Refer to service bulletin SF-054
51	10123533	MANUAL RESET LIMIT - ROS (M1)	371 20162903	PRIMARY LIMIT - BLUE (M1, M2, M4, M5)
51	10123538	MANUAL RESET LIMIT - ROS (M3, M6)	NS 0121F00582	INSULATION, RETAINER (M1)
51	10123539	MANUAL RESET LIMIT - ROS (M2, M4)	NS 0121F00583	INSULATION, RETAINER (M2, M3)
61	0163F00007	MANIFOLD (M1)	NS 0121F00584	INSULATION, RETAINER (M4, M5, M6)
61	0163F00008	MANIFOLD (M2)	NS 0121F00585	INSULATION, RETAINER (M7)
61	0163F00009	MANIFOLD (M4, M5)	NS 0121F00439	PRIMARY LIMIT-HEAT SHIELD
61	0163F00010	MANIFOLD (M6)	NS 0121F00355	SHIELD, COIL (QTY 2)
61	0163F00011	MANIFOLD (M7)		
61	0163F00014	MANIFOLD (M3)	Expanded Model Nomenclature	
71	0163F00017	BECKETT BURNER (QTY 2)	M1 - GMES960403ANAA M2 - GMES960603BNAA M3 - GMES960803BNAA M4 - GMES960804CNAA M5 - GMES960805CNAA M6 - GMES961005CNAA M7 - GMES961205DNAA	
81	0121F00456	BRACKET-BURNER 2 (M1)		
81	0121F00455	BRACKET-BURNER 3 (M2)		
81	0121F00454	BRACKET-BURNER 4 (M3, M4, M5)		
81	0121F00453	BRACKET-BURNER 5 (M6)		
81	0121F00451	BRACKET-BURNER 6 (M7)		
111	0121F00469	ORIFICE BRACKET-BURNER 2 (M1)		
111	0121F00468	ORIFICE BRACKET-BURNER 3 (M2)		
111	0121F00467	ORIFICE BRACKET-BURNER 4 (M3, M4, M5)		
111	0121F00466	ORIFICE BRACKET-BURNER 5 (M6)		
111	0121F00465	ORIFICE BRACKET-BURNER 6 (M7)		
131	0161F00024	COVER, FRONT (M3)		
131	0161F00026	COVER, FRONT (M6)		
131	0161F00030	COVER, FRONT (M4, M5)		
131	0161F00054	COVER, FRONT (M2)		
131	0161F00080	COVER, FRONT (M1)		
131	0161F00066	COVER,FRONT (M7)		
141	0154F00026	GASKET FRONT COVER (M2, M3)		
141	0154F00030	GASKET FRONT COVER (M4, M5, M6)		
141	0154F00034	GASKET FRONT COVER (M7)		
141	0154F00062	GASKET FRONT COVER (M1)		
151	0257F00446	ASSY, HEAT EXCHANGER (M1)		
151	0257F00240	HEAT EXCHANGER ASSY (M4, M5)		
151	0257F00257	HEAT EXCHANGER ASSY (M7)		
151	0257F00280	HEAT EXCHANGER ASSY (M6)		
151	0257F00374	HEAT EXCHANGER ASSY (M2)		
151	0257F00379	HEAT EXCHANGER ASSY (M3)		
161	M0326804	TUBE PLUG		
171	0121F00539	SHEILD, BURNER (M1)		
171	0121F00540	SHEILD, BURNER (M2)		
171	0121F00541	SHEILD, BURNER (M3, M4, M5)		
171	0121F00542	SHEILD, BURNER (M6)		
171	0121F00543	SHEILD, BURNER (M7)		
181	0154F00043	GASKET ID BLOWER		
231	A1781105	CAP-VINYL .500		
261	0121F00317	COVER, REAR (M2, M3)		
261	0121F00318	COVER, REAR (M4, M5, M6)		
261	0121F00319	COVER, REAR (M7)		
261	0121F00670	COVER, REAR (M1)		