

Floor furnaces circulate warm even heat through natural convection.

Heat large areas with this quiet, easily installed, space saving furnace.

Williams' floor furnaces use no above-the-floor room space as it unobtrusively and efficiently circulates warm air, and does this without the aid of a blower.

> Our models are fitted with an automatic floor register grille temperature control and nonelectric pilot to ensure continuous heat - even during power outrages.



45,000 - 60,000 Btu/hr.

Design Features

- No electricty required
- "Matchless" pilot Igniter
- Easy installation
- Combustion chamber lifts out for easy servicing
- Long-life and quiet heavy-duty burner
- Wall-mounted thermostat included
- Natural and propane gas models (Conversion kit available)
- Automatic temperature and safety controls
- Resettable vent-limit safety switch

Floor Furnace

Model Number		Btu/hr.	Btu/hr.	Efficiency Percentages		Dimensions			Floor Opening		Shipping
Natural	Propane	Input	Output	Thermal	AFUE	Width	Length	Height	Width	Length	Weight (lbs.)
4505622A	4505621A	45,000	31,500	70.0	58.0	24"	32"	281⁄2"	241⁄4"	323/8"	147
6005622A	6005621A	60,000	42,000	70.0	58.0	24"	42"	281⁄2"	241⁄4"	423/8"	174

All units have 1/2" gas connection

Features

"Matchless" Pilot Igniter

A self-generating millivolt electrical system powers a wallmounted heating thermostat. This provides maximum room comfort while allowing economical automatic operation.

Floor Register Temperature Control

Williams' floor furnaces are equipped with an automatic floor register grille temperature control. This meets the latest American National Standards Institute Requirements. In extreme weather conditions, this control can be overridden to allow increased heat output.

Dimensions and Clearances

- 6" between the floor furnace and adjacent walls.
- 12" between the floor furnace and doors, draperies or other combustible materials.
- 15" walk space along two sides of the furnace.



All units have a 4" flue pipe and 18" floor-to-center of the flue connection







Great During



250 West Laurel Street · Colton, California 92324 USA (909) 825-0993 · Fax: (909) 370-0581 or (909) 824-8009 Consumer Line: (888) 256-6465 Website: www.e-wfc.com

facebook.com/WilliamsProducts · linkedin.com/company/williams/ twitter.com/WilliamsProduct · youtube.com/user/WilliamsProduct

Easy Installation



	Natur Model N		L.P. Gas Model Numbers		
ELEVATION	45,000 Btu/hr.	60,000 Btu/hr.	45,000 Btu/hr.	60,000 Btu/hr.	
2,001 to 4,000'	4515622A	6015622A	4515621A	6015621A	
4,001 to 6,000'	4535622A	6035622A	4535621A	6035621A	
6,001 to 8,000'	4555622A	6055622A	4555621A	6055621A	

Important

- Read owner's manual before using/installing
- Photographs are representative only.
- Check local codes and ordinances for permitted uses. Consult installation manual for clearances prior to installation.
- We reserve the right to amend product specifications without notice.
- Installation and servicing recommended by a qualified service person. Venting must comply with the"Venting and Chimney Requirements" section of
- the installation manual. Massachusetts approval G1-0813-41.
- Please read the warranty for any limitations or disclaimers. Combustion chamber
- carries a ten-year limited warranty. All other parts carry a one-year limited warranty Replacement floor furnaces of the same or lesser Btu/hr. input rating may be installed in the same location as the replaced furnace when replacement does not create an
- unsafe condition.