

# Installation of Base Legs


## Models 4291 and 4292

Before installing heater to the base legs make sure you have the following items:


(2) - Base Leg (4) - Screws

Installation Procedure:

1. Set the back of the heater on table with the bottom of heater extending beyond the table edge.
2. Fasten the base legs to heater using the screws.



**Model : 4292**



**Model : 4291**