




L1 L2 are the incoming power. Either hot wire can connect to either L1 or L2 ground goes to any green ground screw.



1 and 2 are the power out to the air handler and 3 is communication. The ground wire can go to any green ground screw. Make sure to use 14 gauge, 4 conductor, stranded, shielded or unshielded wire. Using anything else will cause communication errors. Do not splice the 14/4 wire as that will cause communication errors too. If buying the wire from us we recommend connecting Black to 1 red to 2 white to 3 and green to a ground screw.



Location to install the WFWM wifi adapter. Sold separately.



Remove this panel to access the wire connection on the indoor unit